


Changing WIFI trigger strength



April 2016

When you have multiple WIFI hotspots you can change the strength (trigger value) that the device uses to swap between hotspots




1) Turn off WIFI

- 1) Press on the WIFI logo to enter WIFI menu
- 2) Press 3 small squares
- 3) Press on advanced



- 1) Select Roaming
- 2) Select Choose Trigger Level



- 1) Select your desired trigger level (-65 is a stronger signal than -75)
- 2) Return to WIFI menu and turn WIFI back on

